

CARE INSTRUCTIONS

SOLID WOOD OUTDOOR FURNITURE



Karpenter's solid wood furniture has a durability and strong characteristic to make outdoor furniture. Durability and functionality of solid wood products that exposed to the outside environment require periodic control and treatment.

This guide provides recommendation on the best way to care and preserve your solid wood outdoor furniture to keep its longevity and durability.



CLEANING

Upon receiving the furniture, use a soft cloth to clean the dust. The proper cleaning of outdoor items is the first important step for regular maintenance. Natural phenomenon such as acid rain and air pollution are decreasing the durability of the finishing.

- Always use a dry cloth to clean the dry dust on the furniture surface
- Avoid spill of wine, coffee, and tea (as well as other cooking materials) by placing tablecloth/placemat on table surface
- To prevent the finishing fade off, do not expose the furniture directly to salt water/sea water
- Any liquid spill must clean immediately to prevent stain.
 Should the stain has already formed, use the soft sanding sponge (1000 grit) and sand the affected surface slowly right after the stain formed.

IN ANY CASE, DON'T USE ANY CLEANING DETERGENTS CONTAINS AMMONIA OR ALCOHOL-BASED. USE A NATURAL PH CLEANER (NATURAL MATERIAL WILL BE BEST) TO MAINTAIN THE FURNITURE OVER TIME.

RETOUCHING & RENEWING FINISHING

If the finishing coat is damaged due to any external cause, immediately restoring action need to be done. The outdoor finishing should protect the products from the water penetrating inside the wood knowing that any damaged of the finishing can cause more serious damage to the underlying wood.

The finishing renewal should be done on surface in good condition. By the means that the surface has not be damaged, neither any cracks on the finishing and wood nor the fissures.

SHOULD THE FURNITURE NEED TO BE RE-TOUCHED OR RE-FINISHED, PLEASE CONTACT US TO GET THE RIGHT INSTRUCTION TO DO.

POINT TO REMEMBER

- Do the regular checkup finishing surface at least twice a year (one before summer and one before winter) to understand the finishing condition and keeping always in perfect condition.
- When cleaning the surface, always works in the direction of the wood grain.
- Use placements and/or coasters to prevent hot pots and pans, or cold glasses and bottles, from leaving marks on the furniture.
- Do not drag the furniture along the floor; always lifts the furniture when moving.
- Should the furniture is not in used for a certain period of time, please consider to cover the furniture or move it under the roof area.

To maintain the natural beauty, outdoor furniture is **NOT** free maintenance, we strongly recommend to follow our maintenance and care

Designed by Us Defined by Nature

SOLID WOOD ONLY®

www.karpenter.com